

WE OFFER
PERFECT
MIXING
TECHNOLOGIES



PHARMACEUTICAL



NUTRACEUTICAL



FOOD



CHEMICAL



BIO



HEALTH & BEAUTY

PSG SIGMA MIXER | MIXTRUDER

PSG SIGMA MIXER/MIXTRUDER

The PerMix PSG series Sigma Mixer, which is also known as the Double Sigma Mixer, or Double Z Blade Mixer, is used for the mixing-kneading of materials with very high viscosity (over 500,000 cps).

With its unique design of Z-shaped mixing tools installed in two semi-cylinders, the PerMix PSG series Sigma Mixer is able to provide a combined functions of compressing, stretching, folding, kneading & mixing, which makes it widely used in the chemical, food, sealing compound and paint industries, among others. If a screw extruder is applied for discharging, the mixer is also called Sigma Mixer Extruder, or Mixtruder.



HOW IT WORKS

In the PerMix PSG series Sigma Mixer, there are two special designed Z-shaped rotating elements installed in a W-shaped chamber, the intersection of which forms a saddle piece and meeting tangentially just above the saddle. They rotate at different speeds (usually in the ratio of 3:2) and in opposite direction.



The mixing action is a combination of bulk movement, smearing, stretching, folding, dividing, and recombining as the material is pulled and squeezed against blades, saddle, and side walls. Continually new layers of material are compressed and folded over one another and are subjected to shearing forces. New surfaces are formed and the components can penetrate.

The blades, which are ground and polished, successively sweep all points of the trough surface during each revolution, at the same time dividing the batch continuously across the saddle piece and thereby rapidly affecting a perfectly homogeneous mix.

DISCHARGE ARRANGEMENT

For PerMix PSG Sigma Mixers, There are mainly three ways for discharging the product after mixing:

Tilting Tank

For small machines (PSG-1 to PSG-15), tilting can be done manually with a mechanical type (handlever or hand-wheel). For greater machines, electro-mechanically or hydraulically powered tilting system is supplied. PerMix supplies the feature that at tilted position, the blade will rotate at low speed (usually 20% of full speed) in reverse direction to aid the discharge by pushing two buttons with both hands.

Extrusion Screw

The extrusion-discharge screw is located in the saddle section and runs in a cylindrical trough tangential to, and below the 2 mixing blades. When the Sigma Mixer is with the discharge screw, we call it Sigma Mixtruder, and the model name is PSG-X.

During the mixing cycle the screw moves the material within the reach of the mixing blades, thus assuring a thorough blending of all the ingredients, and, at the same time, accelerating the mixing process. At discharge time, the direction of rotation of the screw is reversed and the mixed material is extruded through suitable die openings in the side of the machine. The extrusion screw has its own separate drive so that blades and screw operate independently.

Other Arrangement

Other discharging options are available against request, such as ball valves, or sliding valves mounted at the trough bottom.

OPTIONS

The large number of options available for the PerMix PSG series Sigma Mixer enable it to perform particular functions or operate as a general kneader:

- Quick disassembly & Easy cleaning design
- Lab-size for R&D applications (Full volume of 1, 3, 5, 15L)
- Overlapping arms
- Special 'Duplex' kneading arms for intensive kneading
- Variable speed drive
- Hydraulic powerpack for tiltable trough
- Vacuum execution
- Welded jacket to the trough for heating & cooling
- Bored shaft / arms for heating & cooling



SPECIFICATIONS

Sigma Mixer with Tilting Discharge (PSG)

Model	Total capacity (liter)	Working capacity (liter)	Power for Arms, kW (high viscosity)	Power for Arms, kW (very high viscosity)	Arm Speed, rpm	Length (mm)	Width (mm)	Height (mm)
PSG-1	1	0.6	1.1	2.2	60/47	550	450	700
PSG-3	3	2	1.1	2.2	65/40	650	500	700
PSG-5	5	3.5	1.1	2.2	65/40	700	550	730
PSG-10	10	6	1.5	3	50/35	900	580	691
PSG-15	15	10	2.2	5	50/28	1053	623	861
PSG-50	50	30	3~5.5	5.5~11	43/27	1330	910	1350
PSG-100	100	60	5.5~7.5	11~15	40/25	1588	984	1452
PSG-150	150	90	5.5~11	11~15	40/25	1780	990	1600
PSG-200	200	120	7.5~15	15~22	41/26	1988	1000	1829
PSG-300	300	180	7.5~22	15~30	33/22	2730	1930	1745
PSG-400	400	240	11~30	22~37	33/22	2850	1950	1800
PSG-600	600	360	30~37	55~75	35/23	3070	2080	1870
PSG-800	800	480	30~45	55~90	32/21	3270	2250	1950
PSG-1000	1000	600	37~55	75~110	32/21	4080	1560	2055
PSG-1500	1500	900	45~75	90~160	29/19	4600	1700	2330
PSG-2000	2000	1200	55~75	110~160	29/19	5100	1850	2600

- All specifications are as accurate as is reasonably possible, but they are not binding.
- Arms speed can be specified by the customer.
- Customized sizes are available against request.
- PerMix reserves the right to modify the design without notice.

SPECIAL 'DUPLEX' KNEADING ARMS

PerMix offers PSG-D series 'Duplex' Sigma Mixer which is specially designed for even more intensive kneading applications. They are twin basin kneading machines with two horizontally arranged kneading blades, which are deeply geared into one another and strip themselves reciprocally. The kneading blades are turning acc. to a ratio 1:2.

Because of their different speeds, the blade sides approach and withdraw alternately. This causes high pressure tensile and shearing rates and therefore heavy friction in the kneading medium, which creates excellent dispersing and homogeneity. The shape of the kneading blades enables a steady flow of material from the side walls of the kneading trough to the middle of the kneading trough.



SPECIFICATIONS

Mixtruder with Screw Discharge (PSG-X)

Model	Total capacity (liter)	Working capacity (liter)	Power for Arms, kW (high viscosity)	Power for Arms, kW (very high viscosity)	Arm Speed, rpm	Power for Screw, kW (high viscosity)	Power for Screw, kW (very high viscosity)	Screw Speed, rpm
PSG-1X	1	0.6	1.1	2.2	60/47	0.55	1.1	59
PSG-3X	3	2	1.1	2.2	60/47	0.55	1.1	59
PSG-5X	5	3.5	1.1	2.2	60/47	0.55	1.1	59
PSG-10X	10	6	1.5	3	53/38	0.75	1.5	60
PSG-15X	15	10	2.2	5	50/28	1.1	2.2	60
PSG-50X	50	30	3~5.5	5.5~11	43/27	1.5	3	58
PSG-100X	100	60	5.5~7.5	11~15	40/25	3	4	58
PSG-150X	150	90	5.5~11	11~15	40/25	3	5.5	57
PSG-200X	200	120	7.5~15	15~22	41/26	3	5.5	51
PSG-300X	300	180	7.5~22	15~30	33/22	4	7.5	51
PSG-400X	400	240	11~30	22~37	33/22	5.5	11	51
PSG-600X	600	360	30~37	55~75	35/23	11	30	53
PSG-800X	800	480	30~45	55~90	32/21	11	30	53
PSG-1000X	1000	600	37~55	75~110	32/21	15	37	50
PSG-1500X	1500	900	45~75	90~160	29/19	18.5	45	45
PSG-2000X	2000	1200	55~75	110~160	29/19	22	55	45

- All specifications are as accurate as is reasonably possible, but they are not binding.
- Arms speed can be specified by the customer.
- Customized sizes are available against request.
- PerMix reserves the right to modify the design without notice.

PerMix Tec Co., Ltd.

Room 1-1214, No.1888,
N. Shengxin Rd, Jiading,
Shanghai, 201807, China

Tel: +86-133-9116-8218

Fax: +86-21-3375-8218

www.permixtec.com

www.permix-mixing.com

PerMix in China

Shanghai, 201821, China

Contact: Mr. Aaron Huang

Tel: +86 133 911 68218

Email: aaron.h@permixtec.com

PerMix in Israel

Adi 17940, Israel

Contact: Mr. Arie Srugo

Tel: +972-54-908-0144

Email: srugoa@permixtec.com

PerMix North America

Chicago, Illinois,

60601, USA

Contact: Mr. John Paul

Tel: +1 630-649-1357

Email: John.paul@permixtec.com

South America office

Buenos Aires, Argentina

Contact: Mr. Gonzalo Villagra

Tel: +54-9-11-35374801

Email: gonzalo.villagra@permixtec.com

UK office

Scotland, UK

Contact: Mr. James Ryder

Tel: +44 (0) 7554139667

Email: james.ryder@permixtec.com

South Africa office

South Africa

Contact: Mr. Martin Whelan

Email: saf@permixtec.com

Russia office

Contact: Mr. Vladislav Dyuzhev

Tel: + 7 910 443 9924

Email: ru@permixtec.com

Ukraine office

Contact: Mr. Viacheslav Pishyi

Tel: +38 067 45 44 694

Email: ua@permixtec.com

